



TABLE OF CONTENTS  
STANDARD AND RPO EQUIPMENT  
ELECTRICAL EQUIPMENT INSTALLATION MANUAL

INSTALLATION PAGE

ENGINE ASSEMBLY-(STARTER, GENERATOR, DISTRIBUTOR, COIL, WIRING, ETC.)	FS201, 203
FINAL ASSEMBLY-(BATTERY, WIRING, ETC.)	FS301
FINAL ASSEMBLY-(LICENSE LAMP & WIRING)	FS306
FINAL ASSEMBLY-(HORN RING ASSEMBLY)	FS311
FINAL ASSEMBLY-TACHOMETER	FS401
FINAL ASSEMBLY-(HEADLAMP DOOR & BEAM ADJUSTMENT)	FS451
FINAL ASSEMBLY-(PARKING LAMPS)	FS461
FINAL ASSEMBLY-(TURN SIGNAL)	FS471
BODY ASSEMBLY-(DIMMER SWITCH, STARTER RELAY, CIRCUIT BREAKER, WIRING, ETC.)	FS502
BODY ASSEMBLY-(HEADLAMPS, HORNS, REGULATOR, RELAY, WIRING, ETC.)	FS503
BODY ASSEMBLY-ALL MODELS (REAR LAMP, WIRING, FUEL SENDING UNIT)	FS601
INSTRUMENT PANEL-ALL MODELS (CLUSTER, CLOCK, COURTESY LAMP, WIRING, ETC.)	FS701
INSTRUMENTS & CONTROLS	FS721
AUTOMATIC TRANSMISSION WIRING	FS801
OVERDRIVE	FS811
BACK UP LAMP	FS855
ELECTRIC SEAT ADJUSTER (4-WAY SEAT-O-MATIC)	FS870, FS871
ELECTRIC SEAT ADJUSTER (4-WAY)	FS872
ELECTRIC WINDOW & SEAT REGULATOR	FS881
ELECTRIC WINDOW REGULATOR	FS882

ENGINE  
FS201 TO FS300

FINAL  
FS301 TO FS500

BODY  
FS501 TO FS700

INST. PANEL  
FS701 TO FS800

R.P.O.  
FS801 TO FS900

CODE DESCRIPTION	
2-DOOR CONVERTIBLE	4C
2-DOOR HARDTOP	4C



# TABLE OF CONTENTS

CIRCUITS	ELECTRICAL EQUIPMENT INSTALLATION	MANUAL	PAGE
WIRING DIAGRAM - CIRCUIT SYMBOLS	_____		FS90
WIRING DIAGRAM - IGNITION CIRCUIT	_____		FS93
WIRING DIAGRAM - STARTING, CHARGING & AUTOMATIC TRANS. CIRCUITS	_____		FS95
WIRING DIAGRAM - POWER & CHARGING CIRCUIT	_____		FS96
WIRING DIAGRAM - EXTERIOR & INSTRUMENT LAMP CIRCUITS	_____		FS60
WIRING DIAGRAM - GAGE CIRCUIT	_____		FS65
WIRING DIAGRAM - HEATER BLOWER, & ELECT. CLOCK CIRCUITS	_____		FS66
WIRING DIAGRAM - INTERIOR LAMP CIRCUIT	_____		FS70
WIRING DIAGRAM - HORN & CIGAR LIGHTER CIRCUITS	_____		FS75
WIRING DIAGRAM - OVERDRIVE CIRCUIT	_____		FS85
WIRING DIAGRAM - TURN SIGNAL INDICATOR CIRCUIT	_____		FS90
WIRING DIAGRAM - (4-WAY SEAT) CIRCUIT	_____		FS95
WIRING DIAGRAM - (4-WAY SEAT, SEAT-O-MATIC) CIRCUIT	_____		FS96
WIRING DIAGRAM - WINDOW REGULATOR CIRCUIT	_____		FS98

WIRING  
DIAGRAMS  
FS90 TO FS100

FORD MOTOR COMPANY  
ENGINEERING STAFF-DEARBORN, MICHIGAN



TABLE OF CONTENTS  
ACCESSORY EQUIPMENT  
ELECTRICAL EQUIPMENT INSTALLATION MANUAL  
INSTALLATION-KIT- PAGE

BACK-UP LAMP

FS930

HEATER & DEFROSTER-FRESH AIR

FS970, FS971

RADIO RECEIVER (SIGNAL SEEKING)

FS983, FS984

RADIO RECEIVER (SUPPRESSION)

FS985

MANUAL ANTENNA

FS990

MANUAL ANTENNA (DELUXE)

FS991, FS992


DIAL-O-MATIC SEAT

FS994, 995

ACCESSORIES  
FS901 & UP

1957  
THUNDERBIRD

PAGE - FS20



WIRING DIAGRAM-4-WAY SEAT REGULATOR CIRCUIT  
MODELS - ALL